

tendal® WINDOW CLEANING

Minimum
maintenance
1x/year
more often,
if necessary

CLEANING AND MAINTENANCE

For best results, your windows should be cool before cleaning, i.e., they should not have been exposed to heat (from the sun or other sources). Make sure that all dust, sand and gravel have been removed from all parts of the frame. We recommend using the soft brush of your vacuum cleaner.

Our windows are spring-loaded and can be easily removed from the tracks. To clean the windows on both sides, simply remove them from the frame. Wipe with a soft cloth and a mixture of lukewarm water and mild dish soap. Rinse thoroughly to remove all traces of soap and wipe dry. Do not use cleaning products containing bleach, chlorine or ammonia.

For PVC tracks, wipe with a soft cloth. A dry silicone can be applied with a soft cloth to make the panels slide more easily. Do not, under any circumstances, apply oil-based products or products similar to WD-40.



Manufactured by

Groupe

SOMAC

450-508-4400 | 18 300 J.A. Bombardier, Mirabel, QC J7J 0H5 | tendal.ca